

MAKE SURE THAT STOVE DOESN'T TIP!



Many property owners don't realize that anti-tip devices are required for units inspected by MBHP.

The proper installation of a stove requires the attachment of an anti-tip device. These devices are included with all new stoves, but often are not installed.

Stove tip-overs can cause serious injury or death.

Stove tip-overs frequently occur. If a child steps on an open oven door, or a heavy pot is placed on an open door, the door acts as a lever and forces the stove to tip.



Anti-tip brackets can be purchased at any home center or appliance store.

An anti-tip bracket is generally attached to the bottom of the wall behind the stove, and clips to the rear legs. This allows the stove to be moved for cleaning and maintenance. If you do not have the original bracket which was supplied with the stove, brackets can be purchased at any home center or appliance store.

For more information, please call 617-425-6658.